

Lab 4

Inertial Measurement Units

This lecture is part of the RACECAR-MN introductory robotics course.
You can visit the course webpage at mitll-racecar-mn.readthedocs.io.



BEAVER WORKS
Lincoln Laboratory | School of Engineering



7/20/2020
Page 1

Objectives

Main Objective: Use the RACECAR's IMU data to prevent rolling

Learning Objectives

- Use the Physics module to retrieve linear acceleration and angular velocity


Roll Prevention

- Vehicle rollover is a threat for cars and trucks
 - Turning too quickly can cause a vehicle with a high center of mass to roll



Roll Prevention

- It is difficult to roll the RACECAR-MN due to its low center of mass, but we will model this problem by artificially raising the center of mass in RacecarSim




Rolling Prevention

- Rolling is caused by **inertia**
 - When a car turns the inertial force continues linearly, which creates an outward force
- There are various ways to prevent rolling:



Super elevation



Wider turning




Reducing speed

Inertial Measurement Unit (IMU)


- Uses accelerometers and gyroscopes to measure:
 - **Linear acceleration** (acceleration data)
 - **Angular velocity** (gyro data)

Inertial Measurement Unit (IMU)

Accel




Gyro




Inertial Measurement Unit (IMU)

Accelerometer



Gyroscope



Using IMU Data



Group activity


- What benefits are there to having linear acceleration?
- What benefits are there to having angular velocity?
- What concerns do you have about using the IMU data?

Intel RealSense D435i




Acceleration

- Has three values (in m/s^2):
 - Linear acceleration on X-axis, which points to the **right**
 - Linear acceleration on Y-axis, which points **down**
 - Linear acceleration on Z-axis, which points **forward**



Gyro

- Has three values (in radians/sec) :
 - Angular velocity about X-axis (denoted by Ω_x)
 - Angular velocity about Y-axis (denoted by Ω_y)
 - Angular velocity about Z-axis (denoted by Ω_z)



Physics Module

- Retrieves IMU data
- Public Interface
 - `get_linear_acceleration()`
 - `get_angular_velocity()`

Examples



Group activity

```
# Example 1
def update():
    accel = rc.physics.get_linear_acceleration()
    ang_vel = rc.physics.get_angular_velocity()

    if accel[2] > 0.10:
        print("Kachow!")

    if ang_vel[0] > 0.25:
        rc.drive.stop()
```

Examples



Group activity

```
foo = 0
```

```
def update():  
    global foo
```

```
    ang_vel = rc.physics.get_angular_velocity()  
    foo += ang_vel[1] * rc.get_delta_time()
```

```
    if foo < math.pi / 2:  
        rc.drive.set_speed_angle(1, 1)  
    else:  
        rc.drive.set_speed_angle(1, 0)
```